Existing antifouling	New antifouling Seajet 022 Orenji Seajet 030 Warrior Seajet 031 Samurai Seajet 033 Shogun Seajet 034 Emperor A Seajet 036 Endurance	Seajet 021 Eko Seajet 027 Saikō Seajet 040 Shōsha Seajet 038 Taisho	Seajet 037 Coastal Seajet 039 Platinum
Antifouling in poor condition			
Attiva Professional AFP			
Attiva Drake			
Attiva Giraglia			
Awlgrip Awlstar Gold Label			
Boero Corsaire 611			
Boero Altura 619			
Boero Scirocco 622			
Boero Magellan 630			
Boero Mistral 633			
Boero Admiral 933			
Boero Season 952			
Coppercoat			
Hempel Alu Safe			
Hempel Broads			
Hempel Classic			
Hempel Cruising Performer			
Hempel Dynamic			
Hempel Glide Cruise			
Hempel Globic			
Hempel Hard Racing			
Hempel Mille Standard			
Hempel Mille NCT			
Hempel Olympic			
Hempel Silic One			
Hempel Tiger Extra			
International Micron 77/99			
International Micron 350			
International Uni-Pro 250			
International VC17M			
International Cruiser 250			
International Ultra 300			
International Boatguard 100			
International Trilux 33			
International VC Offshore			
Jotun Mare Nostrum			

Existing antifouling	New antifouling Seajet 022 Orenji Seajet 030 Warrior Seajet 031 Samurai Seajet 033 Shogun Seajet 034 Emperor A Seajet 036 Endurance	Seajet 021 Eko Seajet 027 Saiko Seajet 040 Shōsha Seajet 038 Taisho	Seajet 037 Coastal Seajet 039 Platinum
Jotun Megayacht Imperial	■	■	■
Jotun Non Stop	■	■	■
Jotun Racing	■	■	■
Nautix A3	■	■	■
Nautix A3 T. Speed	■	■	■
Nautix A4	■	■	■
Nautix A4 T. Speed	■	■	■
Nautix Marin	■	■	■
Niemeyer	■	■	■
Plastimo Classic	■	■	■
Plastimo Performance	■	■	■
Plastimo Racing	■	■	■
Seahawk Islands 44	■	■	■
Seahawk Islands 77	■	■	■
Seahawk Sharkskin	■	■	■
Seajet 030 / 031 / 033 / 032	■	■	■
Seajet 034 A / 036 / 034	■	■	■
Seajet 021 / 027 / 040 / 038	■	■	■
Seajet 039 Platinum	■	■	■
Seajet Bioclean Eco	■	■	■
Soromap AF2	■	■	■
Stoppani Stopmar	■	■	■
Stoppani Clipper	■	■	■
Stoppani Sibelius	■	■	■
Teflon Antifouling	■	■	■
Tin-Based Antifouling	■	■	■
Unknown Antifouling	■	■	■

■ - Apply antifouling after removing slime or fouling with high pressure fresh water, remove loose antifouling and spot repair with the recommended primer.

■ - As above but light wet-sanding of the existing antifouling is required, then rewash before painting.

■ - As above but apply a barrier coat of Seajet 015 Underwater Primer before applying the new coating.

■ - Remove the existing antifouling and apply the recommended primer system before applying antifouling.

Don't take any risks! Remove existing antifouling in poor condition.