

Platform	Marke	Model	MAX	4D	MAX N (obsolete)	MAX N+	DISCOVER	REVEAL	DISCOVER X	REVEAL X	MAX PRO (obsolete)	C-MAP MM3D	4D/Essential (Obsolete)	Media Type
PC Navigation	3XEL	Smart Skipper									•			Download C-MAP Store
PC Navigation	ADRENA	Tactique	•											Download C-MAP Store
PC Navigation	ADRENA	Tactique V5	•											Download C-MAP Store
Chartplotters	ADVANSEA	C56	•											SD Card
Chartplotters	ADVANSEA	T50	•											SD Card
Chartplotters	ADVANSEA	T56	•											SD Card
Chartplotters	ALPHATRON MARINE	FF-901	•	•										µSD Card
Chartplotters	AMEC	P200		•										µSD Card
Chartplotters	AMEC	P200-CS		•										µSD Card
Chartplotters	AMEC	P200-SO		•										µSD Card
Chartplotters	ASTRA YACHT	ESA D7 / D7 WiFi	•	•										µSD Card
Chartplotters	B&G	Zeus SR							•	•				µSD Card
PC Navigation	B&G	Sailmath - Deckman	•											Download C-MAP Store
Chartplotters	B&G	Vulcan 7/9			•	•	•	•						µSD Card
Chartplotters	B&G	Zeus			•									µSD Card
Chartplotters	B&G	Zeus Touch			•									µSD Card
Chartplotters	B&G	Zeus2			•	•	•	•						µSD Card
Chartplotters	B&G	Zeus2 Glass Helm			•	•	•	•						µSD Card
Chartplotters	B&G	Zeus2 Touch			•	•	•	•						µSD Card
Chartplotters	B&G	Zeus3			•	•	•	•						µSD Card
Chartplotters	B&G	Zeus3 Glass Helm			•	•	•	•						µSD Card
Chartplotters	B&G	Zeus3S			•	•	•	•						µSD Card
Chartplotters	B&G	Zeus3S Glass Helm			•	•	•	•						µSD Card
Chartplotters	B&G	Zeus S							•	•				µSD Card
Chartplotters	B&G	Zeus S Ultrawide							•	•				µSD Card
Chartplotters	BUSTER	BUSTER Q		•										µSD Card
PC Navigation	CHARTWORX	Quodfish									•			Download C-MAP Store
PC Navigation	CHARTWORX	TheMAP									•			Download C-MAP Store
PC Navigation	CHARTWORX	TRAX									•			Download C-MAP Store
Chartplotters	CIHAN	CME-1512	•											SD Card
Chartplotters	COMNAV	X5	•											µSD Card
PC Navigation	DIGIBOAT	SOB, SOBvMAX	•											Download C-MAP Store
Chartplotters	DIGITAL YACHT	CLA2000	•											µSD Card
Chartplotters	EM-TRACK	AIS A200	•											µSD Card
Chartplotters	EM-TRACK	AIS B400	•											µSD Card
Chartplotters	FURUNO	GP7000/NT	•											SD Card
Chartplotters	FURUNO	GP7000F/NT	•											SD Card
PC Navigation	FURUNO	NavNet 3D										•		Download TZ/FURUNO Store
PC Navigation	FURUNO	Navnet 3D MFD8/12/BB										•		Download TZ/FURUNO Store
PC Navigation	FURUNO	NavNet TZT										•		Download TZ/FURUNO Store
PC Navigation	FURUNO	NavNet TZT2										•		Download TZ/FURUNO Store

[illegible]

[illegible]

[illegible]

[illegible]

Platform	Marke	Model	MAX	4D	MAX N (obsolete)	MAX N+	DISCOVER	REVEAL	DISCOVER X	REVEAL X	MAX PRO (obsolete)	C-MAP MM3D	4D/Essential (Obsolete)	Media Type
Chartplotters	SIMRAD	NSO Evo2			•	•	•	•						µSD Card
Chartplotters	SIMRAD	NSO Evo3			•	•	•	•						µSD Card
Chartplotters	SIMRAD	NSO Evo3S			•	•	•	•						µSD Card
Chartplotters	SIMRAD	NSS			•									µSD Card
Chartplotters	SIMRAD	NSS Evo2			•	•	•	•						µSD Card
Chartplotters	SIMRAD	NSS Evo3			•	•	•	•						µSD Card
Chartplotters	SIMRAD	NSS Evo3S			•	•	•	•						µSD Card
Chartplotters	SIMRAD	NX40	•											SD Card
Chartplotters	SIMRAD	NX45	•											SD Card
Chartplotters	SIMRAD	GO5/7/9/12 XSR			•	•	•	•						µSD Card
Chartplotters	SIMRAD	IDS Display			•	•	•	•						Download (iOS)
Chartplotters	SIMRAD	NSX							•	•				µSD Card
Chartplotters	SIMRAD	NSX ULTRAWIDE							•	•				µSD Card
Chartplotters	SI-TEX	EC11	•											SD Card
Chartplotters	SI-TEX	EC5 (all models)	•											SD Card
Chartplotters	SI-TEX	EC7 (all models)	•											SD Card
Chartplotters	SI-TEX	Explorer NAV PRO/ NAV PRO Wi-Fi	•	•										µSD Card
Chartplotters	SI-TEX	NavPro 1200C/1200F	•	•										µSD Card
Chartplotters	SI-TEX	NavPro 900C/900F	•	•										µSD Card
Chartplotters	SI-TEX	NAVSTAR 10		•										SD Card
Chartplotters	SI-TEX	NAVSTAR 12		•										SD Card
Chartplotters	SI-TEX	SAS-600	•											µSD Card
Chartplotters	SI-TEX	SAS-900	•											µSD Card
Chartplotters	SI-TEX	SNS-1100	•											SD Card
Chartplotters	SI-TEX	SNS-700E/EF	•											SD Card
Chartplotters	SI-TEX	SNS-700I/IF	•											SD Card
Chartplotters	SI-TEX	SVS 1010C/CF	•											SD Card
Chartplotters	SI-TEX	SVS 460C	•											SD Card
Chartplotters	SI-TEX	SVS 560CF	•											SD Card
Chartplotters	SI-TEX	SVS 880C/CF	•											SD Card
Chartplotters	SI-TEX	SVS-750C/CF	•											SD Card
Chartplotters	SI-TEX	SVS-760C/CF	•											SD Card
Chartplotters	SI-TEX	TRAWL PLOT12SD 12.1	•											SD Card
Chartplotters	SRT	Artemis – 5W SOTDMA AIS Class B Transceiver	•											µSD Card
Chartplotters	STANDARD HORIZON	CPN1010i		•										SD Card
Chartplotters	STANDARD HORIZON	CPN700i		•										SD Card
Chartplotters	TECHMARINE	TM11	•											SD Card
Chartplotters	TECHMARINE	TM5 (all models)	•											SD Card
Chartplotters	TECHMARINE	TM7 (all models)	•											SD Card
PC Navigation	TIMEZERO	TZ Coastal Monitoring										•		Download TZ/FURUNO Store
PC Navigation	TIMEZERO	TZ iBoat										•		Download TZ/FURUNO Store
PC Navigation	TIMEZERO	TZ Navigator										•		Download TZ/FURUNO Store

[illegible]